


FITTING INSTRUCTIONS for...

BMW RnineT Scrambler ('16 on)

• BMW RnineT Urban G/S ('17 on)

www.barkbusters.net



Fitting Procedure shown for the LEFT side

٠

(repeat for right side with applicable parts)

Loosely assemble clamp to the handlebar with applicable parts. Attach the handguard backbone with applicable parts to the handlebar end and also to the clamp frame.

Note: The preferred backbone position is horizontal when viewed from the side.


Tighten all bolts in the following order (7), (6), then (4) and (5). Use recommended torque specifications over page.





Phone: +61 (0)2 4271 8244 Email: info@barkbusters.net

Bar Side View



CAUTION:

Installation of the handguard is safety-relevant work and can be complicated. We recommend the installation be performed by a motorcycle service technician. Rideworx accepts no liability for damages caused by improper mounting. All screws, bolts and nuts, including all replacement hardware provided by Rideworx, should be tightened to the torque specified in the table. After the first 50km of riding check all screws, bolts and nuts are tightened to the correct torque. We recommend a medium strength liquid thread lock product on all fasteners.

WARNING:

Check operation of all handlebar controls, specifically the throttle, front brake, kill switch and clutch to ensure they are operating correctly and are in accordance with the OEM specifications. Do not ride the motorcycle if any controls are not operating correctly or if rear view mirror vision is obscured. Check periodically that all bolts are tight.

Phone: +61 (0)2 4271 8244 Email: info@barkbusters.net www.barkbusters.net Web:



|_____

Disclaimer:

A failure to follow these fitting instructions could cause serious injury, death or property damage. These handquards are intended solely for use with motorcycles/ATV/snowmobiles/scooters that have not been modified. They are not designed to prevent injury or death while riding or in an accident or crash. The user must ensure that all controls are free of the handquards every time that they ride. By installing and/or using this product you acknowledge that you accept these terms and have followed the fitting instructions.

INS-BHG-064-00-NP